


**RM-D2014 PIONEER DVD/TV/LCD/LED  
Universal Remote Control  
User Guide**



**English**

**Inputting code:**

1, Turn on your DVD set, let your DVD set be in the normal state play, and aim the remote controller in the front of the DVD.

Find the three digits code from the code list.

2, Press "STANDBY/ON" button, then press "OPEN/CLOSE" button, till the indicator lamp lights, then release the buttons, the remote controller will be in the state of inputting code.

3, Enter the first set of three-digit code in order. When you input each digit, the indicator lamp will flash one time, when you enter all of the three digits, the indicator lamp will turn off, setting to be finished. If the code is more than one set, please use first one at first.

4, Test other function buttons can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

**Русский**

Поиск нужной марки телевизора с помощью ввода кода вручную

1. Включите телевизор и в перечне кодов найдите тот, который соответствует марке Вашего телевизора.

2. Одновременно нажимайте кнопки "STANDBY/ON" и "OPEN/CLOSE", пока не загорится индикаторная лампочка.

3. Введите три первых цифры кода, соответствующего модели телевизора. После ввода кода индикатор перестанет гореть, установка завершена.

4. Проверьте работу кнопок на ПДУ. При наличии проблем повторно выполните процедуру настройки, начиная с шага 2.

For example:

